

PARTS BAG UPC#7146A/#7148A FINISHED BACKS INSTALLATION

PART	Quantity	Reference
Screw	12	A

REQUIRED: #2 Phillips Screwdriver

PARTS

PART	Quantity	Reference
Small Back Panel	1	B
Large Back Panel	1	C

ASSEMBLY

- 1 Attach **Small Back Panel (B)** flush to the top of the assembly using (6) **Screws (A)**.

Attach **Large Back Panel (C)** below the Top Panel using (6) **Screws (A)**.

