


PARTS BAG

UPC 1456

Double Icon 144 Pocket Spinner



PART	Quantity	Reference
Push Pin	26 (2 extra)	A
Long Trusshead Screw	14 (2 extra)	B
Connector Bolt	8	C
Short Trusshead Screw	8	D
Hex Wrench	1	E
Header Clip	2	F



TOOLS REQUIRED: #2 Phillips Screwdriver

PARTS LIST

PART	Quantity	Reference
Top Cap	2	G
Tower Panel	6	H
Spinner Plate Assembly	2	I
Base	1	J
X-Base Lower	2	K
X-Base Upper	1	L
Racks	144	M
Tower Helper	2	N





If you have any questions or need replacement parts, please call:

UPC Customer Service
1-800-859-7442


Design & Manufacture

ASSEMBLY

- 1 Insert **X-Base Upper (L)**
into **X-Base Lower (K)**
as shown below.



- 2 Attach **Base (J)**
to **X-Base Assembly (K/L)** using
(8) **Connector Bolts (C)**



If you have any questions or need replacement parts, please call:


UPC Customer Service

1-800-859-7442


Design & Manufacture

ASSEMBLY

- ③ Spin and align the large holes in **Spinner Plate** with **Spinner**.




Bottom View of Spinner Plate Base (I).




④

Align large screw holes on **Spinner Plate Assembly (I)** with one of the four corresponding holes on the **X-Base Assembly**.




ASSEMBLY



- 5** Attach **Spinner Plate Assembly (I)** to **X-Base Assembly** by using (1) **Short Trusshead Screw (D)** through large screw hole in **Spinner Plate (I)** to hole in **X-Base Assembly**. **DO NOT** tighten completely!



- 6** Turn **Spinner Plate Assembly (I)** 90° to continue attachment to **X-Base Assembly**, slight positioning adjustment may be necessary to find hole. To attach **Spinner Plate (I)**, use 2nd **Short Trusshead Screw (D)** through large hole to corresponding hole of **X-Base Assembly**.



- 7** Repeat Step 6 for attaching **Spinner Plate Assembly (I)** to **X-Base Assembly** using 3rd & 4th **Short Trusshead Screws (D)**. Tighten all screws



8

STOP! If you are installing casters, please refer to instruction sheet **#14562** enclosed in your caster kit.

If you have any questions or need
replacement parts, please call:
UPC Customer Service
1-800-859-7442

Design & Manufacture


ASSEMBLY



NOTE:

Repeat steps **3 - 7** for second
spinner plate assembly.

Finished **X-Base** assembly.




ASSEMBLY



NOTE:

Tower Panel (H) assembly is shown for a single tower.
Repeat steps 9 - 15 for second tower.




9

- A. Peel protective masking off **Tower Panels (H)** before assembly.
- B. Overlap each **Tower Panel (H)** so the large hole of facet lies outside the small hole of adjacent panel. (see figure BELOW)
- C. Use Large Finger Holes to hold **Tower Panels (H)** tightly together while installing **Push Pins (A)**. (see figure RIGHT)
- D. Join (3) **Tower Panels (H)** together using (12) **Push Pins (A)**. Repeat steps for second tower assembly. (see figure RIGHT)


Top of
Tower Panel
(No Slot)

Bottom of
Tower Panel
(With Slot)




ASSEMBLY

- 10** This step will support **Tower Panel Assembly (H)** for installation to Base Assembly. Insert (2) **Tower Helpers (N)** under **Spinner Plate (I)** on base, as shown below.




11


- Align corresponding holes and set the **Tower Panel Assembly (H)** onto the Base Assembly.



- 12** Secure **Tower Panel Assembly (H)** to Base Assembly at middle holes of Tower Panel Assembly. Attach Tower Panels to Spinner Plate edge with (3) **Long Trusshead Screws (B)**. **DO NOT** tighten completely!



- 13** Continue to secure **Tower Panel Assembly (H)** to Base Assembly at corner holes of Tower Panel Assembly. Attach panels to Spinner Plate edge with (3) **Long Trusshead Screws (B)**. Tighten all (6) securely.




If you have any questions or need
replacement parts, please call:


UPC Customer Service
1-800-859-7442

Design & Manufacture

ASSEMBLY



- 14** Remove Tower
Helpers (N).




- 15** Peel masking off Header
Clip (F) and secure to the center
of the Top Cap (G).

Lower Top Cap (G) on to the top
of the Tower Panel Assembly (H).



NOTE:

Tower Panel (H) assembly
is shown for a single tower.
Repeat steps **9 - 15** for second tower.



- 20** Attach **Racks (M)** by hooking the
tabs into the vertical slots in the
Tower Panels (H).

Lock bottom tongue of **Racks (M)**
into the horizontal slots on
the **Tower Panels (H)**.


Each vertical slot holds two
Racks (M) side-by-side.

If you have any questions or need
replacement parts, please call:

UPC Customer Service
1-800-859-7442

Design & Manufacture

ASSEMBLY



Completed assembly.