


## PARTS BAG

Viabella 8080

3" Above Fixture Extender

PART	Quantity	Reference
Screw	8	A
Nut	8	B
Right Bracket	2	C
Left Bracket	2	D



## PARTS LIST


PART	Quantity	Reference
Back Filler Panel	1	E
Sign Track ( <i>Shipped with Display</i> )	1	Q

## ASSEMBLY

**Note: Do Not extend Uprights above the point of four hidden slots.**

- ❑ Attach (4) **Left & Right Brackets (C/D)** to **Back Filler Panel (E)** using (8) **Screws (A)** and (8) **Nuts (B)**. *See Detail below.*
- ❑ Hook assembled **Back Filler Panel (E)** onto front of **Slotted Uprights**. If necessary adjust extension of **Slotted Uprights** by removing **Key**, adjusting and replacing **Key** in appropriate slot.
- ❑ Attach **Sign Track (Q)** (*shipped with Display*) to **Back Filler Panel (E)** using (4) each **Screws (A)** & **Nuts (B)** (*shipped with Display*).

Key In  
Slotted Upright



**Detail**

**Left Bracket shown,  
slots open downward!**

If you have any questions or need replacement parts, please call:

**UPC Customer Service**  
1-800-859-7442

**Design & Manufacture**