

ASSEMBLY INSTRUCTIONS


PARTS BAG

UPC 1458

Icon 63 Pocket Spinner


	Quantity 0 (1 extra) 6 4 4 1	Reference A B C D E F
--	---	---


A COMMON





TOOLS REQUIRED: #2 Phillips Screwdriver


PARTS LIST













ASSEMBLY

1 Insert X-Base Upper (L) into X-Base Lower (K) as shown below.








2 Attach Base (J) to X-Base Assembly (K/L) using (4) Connector Bolts (C).

ASSEMBLY

Spin and align the large holes in Spinner Plate with Spinner.










ASSEMBLY


Attach Spinner Plate
Assembly (I) to
X-Base Assembly
by using (1) Short
Trusshead Screw (D)
through large screw hole in
Spinner Plate (I) to hole in
X-Base Assembly.
DO NOT tighten
completely!




Turn Spinner Plate Assembly (I) 90° to continue attachment to X-Base Assembly, slight positioning adjustment may be necessary to find hole. To attach Spinner Plate (I), use 2nd Short Trusshead Screw (D) through large hole to corresponding hole of X-Base Assembly.

sshead Screw (D)
rge hole to corresponding hole
Assembly.

7
Repeat Step 6 for attaching
Spinner Plate Assembly (I) to
X-Base Assembly using
3rd & 4th Short Trusshead
Screws (D). Tighten all screws









STOP! If you are installing casters, please refer to instruction sheet **#14532** enclosed in your caster kit.

ASSEMBLY




ASSEMBLY

This step will support Tower Panel
Assembly (H) up for installation to Base
Assembly. Insert (2) Tower Helpers (N)
in-between Spinner Plate Assembly (I) and
Base (J), as shown below.




Align corresponding holes and set the Tower Panel Assembly (H) onto the Base Assembly.

(11)




- Secure Tower Panel Assembly (H) to Base Assembly at middle holes of Tower Panel Assembly. Attach Tower Panels to Spinner Plate edge with (3) Long Trusshead Screws (B). DO NOT tighten completely!
 - Base Assembly B

Continue to secure Tower Panel
Assembly (H) to Base Assembly at
corner holes of Tower Panel Assembly.
Attach panels to Spinner Plate edge with
(3) Long Trusshead Screws (B). Tighten
all (6) securely.



ASSEMBLY



Remove Tower Helpers (N).

<u>15</u>)

Peel masking off Header
Clip (F) and secure to the center
of the Top Cap (G). Lower
Top Cap (G) on to the top
of the Tower Panel Assembly (H).



Attach Racks (M) by hooking the tabs into the vertical slots in the Tower Panels (H).

Lock bottom tongue of **Racks (M)** into the horizontal slots on the **Tower Panels (H).**

Each vertical slot holds two **Racks (M)** side-by-side.

